


# GUSD Mobile Hotspot Quick Start Guide

**1** Charge the Hotspot



**2** Power on



**3** Light indicators



**i** Power off Hotspot



The Hotspot is intended for GUSD schoolwork only.

 Hotspot will automatically POWER OFF after 60 min. if not used.

Still have issues?  
For tech support, please call  
818-478-2664

# Connecting a Chromebook to the Hotspot

Any GUSD Chromebook should automatically connect to the GUSD Hotspot.


1. Power on the Chromebook and Hotspot.



2. Click the **time** on the bottom-right of the screen.



3. Click the **Wi-Fi icon**.



4. Chromebook will automatically connect to **CBR-GUSD** Wi-Fi name.

